




Spare Parts Catalog of of Inverter-plus (Heating Only)



(IPH15~IPH70)

CONTENTS

Spare Parts Picture	03-04
IPH15	05-06
IPH20	07-08
IPH25	09-10
IPH30	11-12
IPH35	13-14
IPH45	15-16
IPH55	17-18
IPH70	19-20



①

Inverter board



②

PC Board (Heat&Cool)



③

Touch controller



⑥

Power filter plate



⑧

Reactor(big)



⑪

Electronic expansion valve



⑫

4-way valve



⑬

Water flow switch



⑭

Fan motor



⑮

Fan motor driver module



⑯

Fuse



⑰

Full set of sensors



⑱

Compressor




⑲

Titanium heat exchanger(Heat)



⑳

Evaporator



㉑

High & low pressure protection switch




㉒

High& low pressure valve



㉓

Water union



㉔


Water union gasket




㉕

Fan







Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091310000
2	PC board (Heat&Cool)	033090390000
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092300000
7	Capacitor plate	/
8	Reactor(big)	041301090000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121000001
12	4-way valve	006110080001
13	Water flow switch	040060600000
14	Fan motor	032050510100
15	Fan motor driver module	032050500200
16	Fuse	040070010000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063080000
19	Titanium heat exchanger(Heat&Cool)	001031080002
20	Evaporator	Z01011460000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010140000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040270000
30	Top cover	Z02020701300
31	Front panel	Z020207002Z1
32	Right up panel	Z02020623000
33	Right down panel	Z020206218Z1
34	Back panel	002021210300
35	Bottom board	002021210100
36	Pole	0020206306Z1
37	Left mesh board	Z020206222Z1




Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091310000
2	PC board (Heat&Cool)	033090390000H16
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092300000
7	Capacitor plate	/
8	Reactor(big)	041301090000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121000001
12	4-way valve	006110080001
13	Water flow switch	040060600000
14	Fan motor	032050510100
15	Fan motor driver module	032050500200
16	Fuse	040070010000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063080000
19	Titanium heat exchanger(Heat&Cool)	001031070002
20	Evaporator	Z01011220000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010140000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040270000
30	Top cover	Z02020701300
31	Front panel	Z020207002Z1
32	Right up panel	Z02020623000
33	Right down panel	Z020206218Z1
34	Back panel	0020212025Z1
35	Bottom board	Z02021200100
36	Pole	0020206306Z1
37	Left mesh board	Z020206222Z1




Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091310000
2	PC board (Heat&Cool)	033090390000H21
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092300000
7	Capacitor plate	/
8	Reactor(big)	041301090000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121000001
12	4-way valve	006110080001
13	Water flow switch	040060600000
14	Fan motor	032050510100
15	Fan motor driver module	032050500200
16	Fuse	040070010000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063070000
19	Titanium heat exchanger(Heat&Cool)	001031050002
20	Evaporator	Z01011210000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010140000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040270000
30	Top cover	Z02020701300
31	Front panel	Z020207002Z1
32	Right up panel	Z02020623000
33	Right down panel	Z020206218Z1
34	Back panel	0020207021Z1
35	Bottom board	Z02020700100
36	Pole	0020206306Z1
37	Left mesh board	Z020206222Z1




Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091310000
2	PC board (Heat&Cool)	033090390000H26
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092300000
7	Capacitor plate	/
8	Reactor(big)	041301090000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121000001
12	4-way valve	006110080001
13	Water flow switch	040060600000
14	Fan motor	032050500100
15	Fan motor driver module	032050500200
16	Fuse	040070020000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063020000
19	Titanium heat exchanger(Heat&Cool)	001030780002
20	Evaporator	Z01011110000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010030000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040270000
30	Top cover	Z02020621500
31	Front panel	Z020206202Z1
32	Right up panel	Z02020623000
33	Right down panel	Z020206218Z1
34	Back panel	0020206236Z1
35	Bottom board	Z02020620100
36	Pole	0020206306Z1
37	Left mesh board	Z020206222Z1




Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091310000
2	PC board (Heat&Cool)	033090390000H31
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092300000
7	Capacitor plate	/
8	Reactor(big)	041301080000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121000001
12	4-way valve	006110080001
13	Water flow switch	040060600000
14	Fan motor	032050500100
15	Fan motor driver module	032050500200
16	Fuse	040070020000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063020000
19	Titanium heat exchanger(Heat&Cool)	001030770002
20	Evaporator	Z01011120000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010030000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040270000
30	Top cover	Z02020621500
31	Front panel	Z020206202Z1
32	Right up panel	Z02020623000
33	Right down panel	Z020206218Z1
34	Back panel	0020207110Z1
35	Bottom board	Z02020710100
36	Pole	0020206306Z1
37	Left mesh board	Z020206222Z1



Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091310000
2	PC board (Heat&Cool)	033090390000H43
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092300000
7	Capacitor plate	/
8	Reactor(big)	041301100000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121000001
12	4-way valve	006110210001
13	Water flow switch	040060600000
14	Fan motor	032050500100
15	Fan motor driver module	032050500200
16	Fuse	040070030000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063030000
19	Titanium heat exchanger(Heat&Cool)	001030700002
20	Evaporator	Z01011180000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010030000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040210000
30	Top cover	002020591100
31	Front panel	0020206305Z1
32	Right up panel	002020592500
33	Right down panel	002020630800
34	Back panel	0020206328Z1
35	Bottom board	002020630100
36	Pole	0020206306Z1
37	Left mesh board	0020206309Z1



Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091360000
2	PC board (Heat&Cool)	033090390000H51
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092310000
7	Capacitor plate	/
8	Reactor(big)	041301100000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121010001
12	4-way valve	006110210001
13	Water flow switch	040060600000
14	Fan motor	032050500100
15	Fan motor driver module	032050500200
16	Fuse	040070040000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063030000
19	Titanium heat exchanger(Heat&Cool)	001030690002
20	Evaporator	Z01010650000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	/
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010070000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040210000
30	Top cover	002020591100
31	Front panel	0020205905Z1
32	Right up panel	002020560313
33	Right down panel	002020591300
34	Back panel	0020205935Z1
35	Bottom board	002020590100
36	Pole	0020205906Z1
37	Left mesh board	0020205918Z1



Position	Spare parts	Code
A、Electrical Spare Parts		
1	Inverter board	033091360000
2	PC board (Heat&Cool)	033090390000H68
3	Touch controller	034092020001
4	Contactor	/
5	Capacitor	/
6	Power filter plate	033092310000
7	Capacitor plate	/
8	Reactor(big)	041301110000
9	Reactor(small)	/
10	Water pump contactor	/
11	Electronic expansion valve	006121100001
12	4-way valve	006110170001
13	Water flow switch	040060600000
14	Fan motor	032051000100
15	Fan motor driver module	032051000200
16	Fuse	040070050000
17	Full set of sensors	Z35043000200
B、Refrigerating Spare Parts		
18	Compressor	031063060000
19	Titanium heat exchanger(Heat&Cool)	001030710002
20	Evaporator	Z01011190000
21	High pressure protection switch	040050630000
22	Low pressure protection switch	040050130000
23	High&low pressure valve	006080500000
24	Liquid reservoir	006090020000
C、Cabinet & Other Spare Parts		
25	Water union	003990020000
26	Water union gasket	004980050003
27	Fan	007010120000
28	Drainage kit	Z03991700000
29	Compressor insulation cap	004040360000
30	Top cover	002020640900
31	Front panel	0020206403Z1
32	Right up panel	002020643900
33	Right down panel	0020206412P00
34	Back panel	0020206455Z1
35	Bottom board	002020640100
36	Pole	0020206404Z1
37	Left mesh board	0020206417Z1